047U52248

3-WAY MIXING VALVE WITH BONNET R298N





Description

The R298N mixing valve allows for the interception and mixing of heating fluid in radiant heating and cooling systems for floors or ceilings and in medium-size radiator heating systems that require precise control of water delivery temperature.

The R298N valve is equipped with a handwheel for manual operation, or alternatively, it can be coupled to a K281 actuator for automatic control.

Versions and product codes

Product code	Connections	Actuator connection
R298Y024	G 3/4"F	M30 x 1,5 mm (Red handwheel)

Completion codes

• Actuator K281


Accessories

- P19Y001: ring nut M30 \times 1,5 mm for adapting valve R298 M28 \times 1,5 mm threading.
- P19Y002: ring nut M28 \times 1,5 mm for adapting valve R298 M30 \times 1,5 mm threading

Technical data

- Fluid: water for HVAC systems
- \bullet Max. working temperature: 90 °C
- Max. working pressure: 10 bar

Losses of pressure



Operation

R298N + handwheel for manual operation

The 3-way R298N mixing valve is equipped with a handwheel to allow for manual operations, which are carried out via a simple clockwise rotation for the valve opening and anticlockwise for closure.

Total opening of the bonnet, and therefore of the primary side supply, is obtained by screwing down the handwheel, while unscrewing it fully frees the thread for the drive motor connection.

R298N + K281 actuator for automatic operation

The handwheel can be replaced with a K281 actuator for automatic mixing adjustment, in combination with electronic thermoregulation.


The K281 actuator is mounted manually, by screwing the brass ring nut in a clockwise direction until it stops. This does not require the use of any tools.

Installation

• The R298N valve must be installed according to the direction of flow as indicated by the arrow present on the valve body.




• The R298N valve must be installed on the delivery side. The circulator on the secondary circuit must be installed downstream from the mixing valve.



• The R298N valve can be installed in a vertical position with the actuator to the right or left, or in a horizontal position with the actuator above.

Horizontal downward facing installation of the valve is not permitted.





047U52248

3-WAY MIXING VALVE WITH BONNET R298N



Dimensions





Product specifications

R298N

3-way mixing valve with bonnet. Threaded connections G 3/4"F. In brass. Gaskets in EPDM. Max. working temperature 90 °C. Max. working pressure 10 bar. Can be motorized by installing the K281 series actuator.